

BRIC-Link III

Installation Guide Rack Shelf Assembly

Installing Front Bracket

- 1) Remove the front panel from the end of the BRIC-Link III case by removing the 4 - #4-40 x 3/8" black screws. Remove the 4 rubber feet on the bottom of the BRIC-Link III.
- 2) Orient and fasten the case to the rack shelf panel using the 4 - #4-40 x 3/8" black screws. Make sure the case and cover are flush to the rack shelf panel. Gently ensure that all LEDs and buttons are aligned and seated into panel.
- 3) Repeat this process for the second BRIC-Link III case.
- 4) If you are not installing a second BRIC-Link III to the rack shelf panel a blank plate is available to cover the second set of cutouts.
- 5) To install the blank plate, place it over the appropriate holes in the rack shelf panel and fasten it with 4 - #4-40 x 3/8" black screws and 4 - #4-40 x 1/4" kep nuts.
- 6) Place the case and rack shelf panel assembly on the rack shelf, aligning the rack mounting holes at each side.
- 7) Slide everything into your rack and fasten it with the rack manufacturer's suggested hardware.
- 8) Plug the power supply/supplies into the BRIC-Link III(s) and then your audio and Ethernet cables.

